




INFINITI.

GENUINE PARTS

INSTALLATION INSTRUCTIONS

- 1. **DESCRIPTION:** Illuminated Kick Plate
- 2. **APPLICATION:** G37 COUPE
- 3. **PART NUMBER:** G6950 JL100
- 4. **KIT CONTENTS:**

Item	QTY	Description
A	1	Kick Plate LH
B	1	Kick Plate RH
C	1	T-Harness
D	14	Tie Wrap
E	8	Urethane foam tape
F	9	Flat wire protector
G	1	Installation Instructions



- 5. **TOOLS REQUIRED:**
 - Nylon Removal Tool
 - Wire cutter
 - 10mm Socket and driver
 - 14mm socket and driver
 - Fish tape
 - Masking tape
 - Flash light
 - Scissors
 - Soap and water
 - 50/50 alcohol & water solution
 - Soft non linting towel

INSTALLATION INSTRUCTIONS - ILLUMINATED KICK PLATE

6. PRE-INSTALLATION CAUTIONS/NOTES

⚠ CAUTION

- Dealer Installation Recommended. Instructions refer to Service Manual.
- Please read this instruction carefully before installing this product for correct installation.
- Please DO NOT use or install the part in ways other than what is described in this instruction manual.
- If problem occurs during installation, please contact Nissan dealer where you purchased the product.

- 1) Apply Parking Brake.
- 2) Make sure the shift lever is engaged in "P" or "N" position.
- 3) Record customer Radio Presets.


Preset	1	2	3	4	5	6
A						
B						
C						

- 4) Use seat and floor protection.
- 5) Open the hood of the vehicle.
- 6) Disconnect the negative battery terminal to prevent short circuits during installation.
- 7) This part is to be installed at a surface temperature of 65-100°F.
- 8) Do not wash the vehicle for 24 hours after installing to prevent the double-sided tape from peeling.

⚠ CAUTION


- Care must be taken not to scratch or damage any components during the removal or replacement process.

- 9) Remove the following interior trim parts in the sequence shown below.




INSTALLATION INSTRUCTIONS - ILLUMINATED KICK PLATE

7. INSTALLATION OUTLINE




8. STANDARD CONNECTION METHOD




INSTALLATION INSTRUCTIONS - Illuminated Kick Plate


9. VEHICLE PARTS REMOVAL



- 1) Front Kick Plate Inner LH removal
 - a) Pull up front kick plate inner, and disconnect pawls. Shown in Fig 1.
 - b) Remove front kick plate inner (1).




- 2) Front Kick Plate Outer LH removal
 - a) Remove front kick plate outer mounting clips with nylon removal tool, then remove kick plate outer (2). Shown in Fig 2.



- 3) Dashboard Side Lower Panel LH removal
 - a) Remove clip.
 - b) Remove dash side finisher mounting clips with nylon removal tool, then remove Dashboard Side Lower panel (3). Shown in Fig 3.


INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

9. VEHICLE PARTS REMOVAL CONT'D




- 4) Foot Grill LH Removal
 - a) Remove mounting clips, and then remove Foot Grill LH (4). Shown in Fig4.

- 5) REPEAT steps 1)-3) for RH side of vehicle




- 6) Instrument passenger Lower Cover removal
 - a) Pull downward, disengaged pawls.
 - b) Pull back instrument passenger lower cover (5). Shown in Fig5.




- 7) Foot Grill RH Removal
 - a) Remove mounting clips, and then remove Foot Grill RH (4). Shown in Fig6.

INSTALLATION INSTRUCTIONS - Illuminated Kick Plate


10. WIRING HARNESS INSTALLATION



- 1) Disconnect connector (NS16FW) from the BCM.
- 2) Connect (NS16FW) from T-harness (C) to the BCM shown in Fig7.
- 3) Connect the connector(NS16FW) which was disconnected from the BCM to the T-harness (C) shown in Fig7.




- 4) Wrap the connected connector with two pieces of Urethane foam tape (E). Shown Fig8.
- 5) Wrap the fuse of T-harness (C) with two pieces of Urethane foam tape (E). Shown Fig8.




- 6) Attach the fuse of T-harness (C) at the position shown in Fig9, using the tie wrap (D).
- 7) Attach the connected connector to the T-harness (C) at the position shown in Fig9, using the tie wrap (D).

INSTALLATION INSTRUCTIONS - Illuminated Kick Plate


10. WIRING HARNESS INSTALLATION CONT'D



- 8) Attach the T-harness at the position shown in Fig10, using the tie wrap (D). (1piece)




- 9) Remove one push nut from front passenger side carpet. Shown in Fig11.
- 10) Flip the carpet of passenger side.
- 11) Route fish tape behind center console from driver's side harness to passenger side.
- 12) Pull harness with fish tape behind center console.
- 13) Put a flat wire protector (F) near a tie wrap (D) of view A without pulling harness. (1place)
- 14) Attach passenger side harness using the flat wire wire protector (F) shown in Fig11. (4places)




- 15) Flip the carpet of the driver's side and attach harness to floor using flat wire protector (F) shown in Fig12. (4places)

INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

10. WIRING HARNESS INSTALLATION CONT'D



- 16) Route harness through existing vehicle harness protector and Tie Wrap (D) the harness at the position shown in Fig13. (3 places)




- 17) Route harness through existing vehicle harness protector and fix the harness at the position shown in Fig14, using the tie wrap (D). (3places)


INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

11. KICK PLATE INSTALLATION

The procedure below shows the installation for RH side.
Repeat procedure for LH side.



- 1) Remove the vehicle weather strip near the kick plate (B) attachment location shown in Fig15.
- 2) Clean the attachment area of kick plate (B) with soapy water.
- 3) Dry area with soft non linting towel.
- 4) Clean area with 50/50 alcohol & water solution and let dry for 30 seconds.



- 5) Remove location a and b double-sided tape's liner shown in Fig16.
- 6) Pull the adhesive tape liner pull tab to partially remove liner from all other locations. Using masking tape, hold the liner to the visible side of the kick plate (B) surface as shown in Fig16.
- 7) Align pins on part to second and fourth hole on vehicle from front side.
- 8) Set part on vehicle, being careful to keep the outside edge of the part parallel to the rocker panel.
- 9) Gradually remove the tape liner at the back of the kick plate (B) starting from the front, apply minimum 11lb(49N) of pressure along the part to attach tape to body shown in Fig16.


⚠ CAUTION

- Use caution when applying pressure as the surface may dent.
- During installation, be careful not to allow the harness to get stuck between the vehicle and the kick plate.
- Harness should be routed through the notched area of the kick plate.


INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

12. HARNESS CONNECTION INSTALLATION

The procedure below shows the installation for RH side.
Repeat procedure for LH side.



- 1) Fold one piece urethane foam tape (E) and cut into two equal pieces.
- 2) Clean both sides of the attachment area for the urethane foam tape (E) with the 50/50 alcohol & water solution. Let dry for 30 seconds. Shown in Fig17.



- 3) Attach the cut piece of urethane foam tape (E) to vehicle flange shown in Fig18.
- 4) Place the lamp harness on top of the urethane foam tape (E), then apply second half of the urethane foam tape (E) on top of the harness.
- 5) Connect the connectors and apply the urethane foam tape (E) on the connecting section shown in fig18.
- 6) Attach excess lamp harness to the vehicle harness with a tie wrap (D) shown in Fig17
- 7) Cut excess tie wrap.

CAUTION

- Do not attach the harness to sharp metal edge

INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

13. CHECK AFTER INSTALLATION

- 1) Please check that the installation has no problem.
 - a) confirm connection of connector
 - b) confirm whether wire harness is fixed.

14. FUNCTION CHECK

- 1) Re-connect battery negative terminal.
- 2) Confirm "INFINITI" text is illuminated when either door is in the opened position.

15. REINSTALLATION OF REMOVED PARTS

- 1) All removed vehicle parts have been reinstalled.

CAUTION

- Use caution when re-installing interior components to avoid damage, scratch, or breaking of mounting clips.

- 2) Clean interior of vehicle.

16. VEHICLE CHECK

- 1) Remove all tools from the vehicle.
- 2) Inspect reinstalled interior trim parts for proper panel fit.
- 3) Reset radio presets to the recorded setting.
- 4) Turn ignition to ON position.
- 5) Confirm proper radio operation.
- 6) Initialize sun roof, and power window operation.
- 7) Confirm proper operation of the rear window washer fluid.
- 8) Turn ignition to off position.

CAUTION

- During restoring, please use caution so as not to cause the stacking of the vehicle's harness, or damage any other parts.